Boxy
Pen & Gadget box

Frees up workspace

Handy gadget box for mounting under the desktop, which houses both pens, scissors, paper clips, 30 inch ruler and much much more. Elegant recessed under desk for storage. Built-in lock braking in the closed position and firm rotation.



SPECIFICATIONS

- Both wise and practical
- Clean and tidy with a free working space on the desk, holds both scissors and a ruler (30 cm)
- Swivel 360°
- Dimensions: See drawing.
- Easily installed with attached 2 screws
- Part no 435-4487 Boxy Black
  Part no 435-4488 Boxy White